
HumPRO™ Series Master Development System

Quick Start Reference









2 Set Up the Programming Docks

MDEV-fff-PRO

MDEV-A-fff-PRO





With the power off, set up boards by inserting EVMs into sockets on the Programming Docks and attaching the antennas.

Remove kit contents including development boards, antennas, batteries, modules and USB cables.



3 Install the Software



Install the Windows software from the CD that is included with the kit. If already installed, skip this step.






Connect the Programming Docks to a computer with the cables included with the kit. USB drivers are on the CD so install them if prompted by the computer.

5 Start the Software



Start the software. It automatically detects conected modules and reads their configurations.



Warning: Installing or removing a Carrier Board while power is applied could cause permanent damage to the module. Either turn off power to the board or unplug the USB cable before installing or removing a Carrier Board

Note: The LNA_EN and PA_EN lines are not wired out on the HUM-A-900-PRO.