


# Series LUMOTAST FK

16.2 mm mounting hole diameter

1


LUMO  
FK

## Mounting




- ① pushbutton as supplied
- ② Insert pushbutton into panel cut-out
- ③ Press once to fit
- ④ Attach connector with flat-ribbon cable


## Disassembly from front side




1. Grip body/lens



2. Pull out body/lens



3. Release click lever




4. Pull out pushbutton/signal lamp with cable

# PUSHBUTTONS


LUMOTAST FK - ILLUMINATED PUSHBUTTONS

## Dimensional drawing

With quick connector and flat-ribbon cable




Connection diagram (PCB top view)




1 + 4 = pushbutton connection, 2 + 3 = lamp connection  
If LED is used: connection 3 = cathode


With plug-in socket





Plug-in socket for PCB



Front panel top view



PCB top view



PCB hole diagram  
Sight on component side

