


### **Manual Switches**


# Mounting Dimensions (For Reference Only)




# Mounting Dimensions (For Reference Only)







AML33/35 SWITCHES



# PANEL CUTOUT FOR SINGLE-STATION FRONT-OF-PANEL MOUNTING WITH SHORT BARRIERS WITH LONG BARRIERS Recommended panel thickness: .060-.187/1,52-4,75

**NOTES** 

60

1 Dimensions are mm or mm/IN IN

2 Manufacturers logo on this side of housing Solder Hole Will Accept One #14 AWG Stranded Conductor (Per NEMA Publication DC-2 1976)


#### PANEL PUNCH FOR AML SERIES

A panel punch is manufactured by Greenlee-Textron Tool Co., Rockford, IL (815-926-3011).


### **Manual Switches**

### Mounting Dimensions (For Reference Only)


#### **TERMINAL LOCATIONS FOR AML10 SWITCHES**



#### **TERMINAL LOCATIONS FOR AML41 INDICATORS**




#### TERMINAL LOCATIONS FOR AML42 INDICATORS




Manual Switches AML Series

### Mounting Dimensions (For Reference Only)



#### **ANNUNCIATORS**



For panel punch manufacturer, see page 60.

# Mounting Dimensions (For Reference Only)

#### **MULTI-STATION FRONT-PANEL MOUNTING**

Panel cutouts (See page 61 for panel punch manufacturer.)

Square Switches & Indicators	Rect. Switches & Indicators	Annunciator
(.8) (No. of units) — .045*	(1.20) (No. of units) — .045*	(.40) (No. of units) — .045*
(20,3) (No. of units) — 1,14*	(30,5) (No. of units) — 1,14*	(10,1) (No. of units) — 1,14*

For each barrier, add .053/1,35

#### **AML61 MULTI-STATION SUBPANEL MOUNTING**

#### Panel cutouts for AML61


Mounting Bra Orientation	cket	Width	Length		
A*	in. mm	.810 20,57	(.810)(No. of units)		
В	in. mm	.810 20,57	(1.210)(No. of units)		
C or D*	in. mm	1.210 27,94	(.810)(No. of units)		


<sup>\*</sup> More than two cans with mounting brackets required for strips of more than 10 units.


#### **AML61 MOUNTING CENTERS**

Mounting Bracket Orientation		Mounting Centers/Number of Cans											
		1	2	3	4	5	6	7	8	9	10	11	12
"A" or "C"	in. mm	1.285 32,64	2.095 53,21	2.905 73,79	3.715 94,36	4.525 114,94	5.335 135,51	6.145 156,08	6.955 176,66	7.765 197,23	8.575 217,81	9.385 238,38	10.195 258,95
"B"	in. mm	1.685 42,80	2.895 73,53	4.105 104,27	5.315 135,00	6.525 165,74	7.735 196,48	8.945 227,20	10.155 257,94				
"D" or "E"	in. mm	on C∟ on C∟	.807 20,50	1.614 41,00	2.421 61,49	3.228 81,99	4.035 102,49	4.842 122,99	5.649 143,48	6.456 163,98	7.263 184,48	8.070 204,98	8.877 225,48

Tolerance =  $\pm .015$ 








<sup>\*</sup> Note: If barriers are used, do not subtract .045 in./1,14 mm from the panel cutout formula. (.045 in./1,14mm is the allowance for the width of the bezel.)

### **AML Series**

### Mounting Dimensions (For Reference Only)




#### **Panel cutouts**

Multiple panel sealed units should not be mounted together in a single elongated slot, since this would create an unsealed space between each unit.

PUSHBUTTON AND INDICATOR


Side-by-side mounting can be achieved, per the center-to-center dimensions shown in the drawing. (Dotted lines indicate the seal bases which are abutting at front of panel.)

AML75 seals are not designed for use with the AML61 mounting system.



PANEL CUTOUTS

NOTE: Suggested cutout dimensions are based on an .125"/3,18 mm panel thickness. Individual preferences for inpanel fit



may require measurement of assemblies before panels are cut.

#### **AML76 SWITCH GUARD ACCESSORY**

