

Release Notes

CYALKIT-E02 Solar-Powered BLE Sensor Beacon Reference Design Kit (RDK)

Release Date: May 17, 2016

Thank you for your interest in the CYALKIT-E02 Solar-Powered BLE Sensor Beacon RDK. This document lists kit contents, installation requirements, kit documentation, limitations, and known issues.

Kit Contents

The CYALKIT-E02 Solar-Powered BLE Sensor Beacon RDK includes the following:

- One Solar-Powered BLE Sensor Beacon (Solar BLE Sensor)
 - Enclosure and board
- One BLE-USB Bridge and Debug Board
- Quick Start Guide

Software and Tools

The code examples shipped with this kit require PSoC® Creator™ 3.3 SP2 or later. This is available with the kit installer or on the PSoC Creator webpage (www.cypress.com/psoccreator).

PSoC Programmer 3.24.2 or later and KitProg v2.14 or later are required to program the Kit. PSoC Creator installation or the kit installation automatically installs PSoC Programmer and KitProg drivers.

Code Examples and Kit Collateral

The CYALKIT-E02 Solar-Powered BLE Sensor Beacon RDK webpage (www.cypress.com/CYALKIT-E02) includes the kit installation packages, DVD image (ISO), and setup files (EXE) to install the code examples, documents, and hardware files of this kit.

Installation

Installation instructions are provided in the CYALKIT-E02 Solar-Powered BLE Sensor Beacon RDK Kit Guide, which is available at www.cypress.com/CYALKIT-E02.

Kit Revision

This is the *B revision of the CYALKIT-E02 Solar-Powered BLE Sensor Beacon RDK.

Limitations and Known issues

The following limitations and issues are known at the time of release of this kit. These will be addressed in future updates to the kit.

- The initial firmware programmed into the debug board does not support the CySmart™ Software Utility. Instead, the firmware is a custom version used to demonstrate the features of this kit.
- For limitations and known issues with the S6AE103A PMIC device, see the [S6AE103A datasheet](#).
- For limitations and known issues with the EZ-BLE™ PRoC™ module, see the [EZ-BLE PRoC Module datasheet](#).

- For limitations and known issues with PSoC Creator, see the [PSoC Creator release notes](#).

Documentation

The kit documents are located in the `Documentation` folder in the installation directory. The default location for the kit documents is:

```
<Install_Directory>\CYALKIT-E02 Solar-Powered BLE Sensor Beacon  
RDK\<version>\Documentation
```

Documents include:

- *CYALKIT-E02_Kit_Guide.pdf*
- *CYALKIT-E02_Quick_Start_Guide.pdf*
- *CYALKIT-E02_Release_Notes.pdf*
- *Cypress BLE-Beacon_PC_Release_Notes.pdf*
- *Cypress BLE-Beacon_Android_iOS_Release_Notes.pdf*
- *Cypress BLE-Beacon_Android_UserGuide.pdf*
- *Cypress BLE-Beacon_iOS_UserGuide.pdf*
- *Cypress BLE-Beacon_PC_UserGuide.pdf*
- *KitProg User Guide.pdf*

PSoC Creator documentation is available under the menu item **Help > Documentation**.

The default location for PSoC Creator documents is:

```
<Install_Directory>\PSoC Creator\<version>\PSoC Creator\documentation
```

The default location for PSoC Programmer documents is:

```
<Install_Directory>\Programmer\Documents
```

Technical Support

For assistance, go to www.cypress.com/support or contact our customer support at:

+1 (800) 541-4736 Ext. 2 (USA), or +1 (408) 943-2600 Ext. 2 (International).

Additional Information

- For more information about PSoC Creator functionality and releases, visit the PSoC Creator webpage: www.cypress.com/psoccreator
- For more information about PSoC Programmer and supported hardware, visit the PSoC Programmer webpage: www.cypress.com/psocprogrammer
- For a list of training material on PSoC Creator, visit www.cypress.com/go/creatorstart/creatortraining



SRN211724

Cypress Semiconductor
198 Champion Ct.
San Jose, CA 95134-1709 USA
Tel: 408.943.2600
Fax: 408.943.4730
Application Support Hotline: 425.787.4814
www.cypress.com

© Cypress Semiconductor Corporation, 2016. This document is the property of Cypress Semiconductor Corporation and its subsidiaries, including Spansion LLC (“Cypress”). This document, including any software or firmware included or referenced in this document (“Software”), is owned by Cypress under the intellectual property laws and treaties of the United States and other countries worldwide. Cypress reserves all rights under such laws and treaties and does not, except as specifically stated in this paragraph, grant any license under its patents, copyrights, trademarks, or other intellectual property rights. If the Software is not accompanied by a license agreement and you do not otherwise have a written agreement with Cypress governing the use of the Software, then Cypress hereby grants you a personal, non-exclusive, nontransferable license (without the right to sublicense) (1) under its copyright rights in the Software (a) for Software provided in source code form, to modify and reproduce the Software solely for use with Cypress hardware products, only internally within your organization, and (b) to distribute the Software in binary code form externally to end users (either directly or indirectly through resellers and distributors), solely for use on Cypress hardware product units, and (2) under those claims of Cypress’s patents that are infringed by the Software (as provided by Cypress, unmodified) to make, use, distribute, and import the Software solely for use with Cypress hardware products. Any other use, reproduction, modification, translation, or compilation of the Software is prohibited.

TO THE EXTENT PERMITTED BY APPLICABLE LAW, CYPRESS MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS DOCUMENT OR ANY SOFTWARE OR ACCOMPANYING HARDWARE, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. To the extent permitted by applicable law, Cypress reserves the right to make changes to this document without further notice. Cypress does not assume any liability arising out of the application or use of any product or circuit described in this document. Any information provided in this document, including any sample design information or programming code, is provided only for reference purposes. It is the responsibility of the user of this document to properly design, program, and test the functionality and safety of any application made of this information and any resulting product. Cypress products are not designed, intended, or authorized for use as critical components in systems designed or intended for the operation of weapons, weapons systems, nuclear installations, life-support devices or systems, other medical devices or systems (including resuscitation equipment and surgical implants), pollution control or hazardous substances management, or other uses where the failure of the device or system could cause personal injury, death, or property damage (“Unintended Uses”). A critical component is any component of a device or system whose failure to perform can be reasonably expected to cause the failure of the device or system, or to affect its safety or effectiveness. Cypress is not liable, in whole or in part, and you shall and hereby do release Cypress from any claim, damage, or other liability arising from or related to all Unintended Uses of Cypress products. You shall indemnify and hold Cypress harmless from and against all claims, costs, damages, and other liabilities, including claims for personal injury or death, arising from or related to any Unintended Uses of Cypress products.

Cypress, the Cypress logo, Spansion, the Spansion logo, and combinations thereof, PSoC, CapSense, EZ-USB, F-RAM, and Traveo are trademarks or registered trademarks of Cypress in the United States and other countries. For a more complete list of Cypress trademarks, visit cypress.com. Other names and brands may be claimed as property of their respective owners.
